



QUANTUM

26 November 2025

QUANTUM SPARK 2580 APPLIANCE

Getting Started Guide



Check Point Copyright Notice

© 2025 Check Point Software Technologies Ltd.

All rights reserved. This product and related documentation are protected by copyright and distributed under licensing restricting their use, copying, distribution, and decompilation. No part of this product or related documentation may be reproduced in any form or by any means without prior written authorization of Check Point. While every precaution has been taken in the preparation of this book, Check Point assumes no responsibility for errors or omissions. This publication and features described herein are subject to change without notice.

RESTRICTED RIGHTS LEGEND:

Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and FAR 52.227-19.

TRADEMARKS:

Refer to the [Copyright page](#) for a list of our trademarks.

Refer to the [Third Party copyright notices](#) for a list of relevant copyrights and third-party licenses.

Important Information



Latest Software

We recommend that you install the most recent software release to stay up-to-date with the latest functional improvements, stability fixes, security enhancements and protection against new and evolving attacks.



Certifications

For third party independent certification of Check Point products, see the [Check Point Certifications page](#).



Check Point Quantum Spark 2580 Appliance Getting Started Guide

For more about this release, see the [home page](#).



Latest Version of this Document in English

Open the latest version of this [document in a Web browser](#).
Download the latest version of this [document in PDF format](#).



Feedback

Check Point is engaged in a continuous effort to improve its documentation.
[Please help us by sending your comments](#).

Revision History

Date	Description
26 November 2025	Updated <i>"Shipping Carton Contents"</i> on page 8
14 August 2025	Reformatted Network LED tables in <i>"Front Panel"</i> on page 35
17 July 2025	First release of this document

Table of Contents

Introduction to the 2580 Getting Started Guide	6
Quantum Spark 2580 Appliance	7
Shipping Carton Contents	8
Mounting the Appliance	9
Connecting the Cables	11
First Time Deployment Options	12
Using the First Time Configuration Wizard	13
Starting the First Time Configuration Wizard	14
Welcome	15
Zero Touch	15
Authentication Details	17
Appliance Date and Time Settings	18
Appliance Name	19
Security Policy Management	20
Internet Connection	21
Local Network	23
Administrator Access	24
Appliance Registration	25
Security Management Server Authentication	27
Security Management Server Connection	28
Software Blade Activation	29
Summary	30
Zero Touch Cloud Service	31
USB Drive	33
Appliance Diagrams and Specifications	34
Front Panel	35
Management LED	37

Network LEDs	38
Back Panel	40
Side Panel	41
Health and Safety Information	42
Informations relatives à la santé et à la sécurité	49
Support	56

Introduction to the 2580 Getting Started Guide

Thank you for choosing Check Point's Internet Security Product Suite. Check Point products provide your business with the most up to date and secure solutions available today.

Check Point also delivers worldwide technical services including educational, professional, and support services through a network of Authorized Training Centers, Certified Support Partners, and Check Point technical support personnel to ensure that you get the most out of your security investment.

For configuration instructions, see the relevant documentation.

For more technical information, go to [Check Point Support Center](#).

Quantum Spark 2580 Appliance

The Quantum Spark 2580 Security Appliances, part of the new 2500 Appliance Series, deliver enterprise-grade security and run the R82 code base in an all-in-one security solution to protect Medium Business employees, network and data from cyber-theft. They offer vast switching capabilities with 24 x 2.5GbE ports, 8 x 1GbE and 2 combo ports (10GbE WAN + SFP ports, and 10GbE DMZ + SFP ports).

The 2580 Security Gateways offer integrated, multi-layered security in a 1U form factor, a high performance platform which is easy and simple to configure and manage. The Security Gateway offers firewall, VPN, Anti-Virus, Application Visibility and Control, URL Filtering, Email Security, and SandBlast Zero-Day Protection.

Quantum Spark 2580 Security Appliances can be managed locally in a Web interface or a cloud-based Quantum Spark Security Management Portal (SMP) application in the Infinity Portal, or centrally by a Smart-1 Management Server.

Shipping Carton Contents

Item	Quantity	Description
Appliance	1	2580 Appliance.
LAN cable	1	1.8m - RJ45 to RJ45, CAT6, shielded, STP, black color.
Console cable	1	1m, USB type-C to USB-2.0 type-A, black color.
Power cord and adapter	1	1x Power Adapter's power cord. 1x Power Adapter AC to 12VC+DC desktop, 60W, black color Plug types: US, UK, EU and AUS/NZ, India, China, Japan.
Rubber feet	4	Pre-assembled on the chassis.
AC cord tie	2	Cable ties to hold the power cords. Thread these ties directly into the back panel of the appliance.
Wall Mount kit	1	Includes drilling hole location illustration sticker.
Welcome Page	1	Welcome to Check Point QR Page

Mounting the Appliance


1. Remove the Quantum Spark 2580 Appliance from the shipping carton and place it on a tabletop.

For other mounting options, see below.

2. **Optional** - Remove the transparent protective sticker from the front panel of the appliance.
3. Identify the network interface marked as LAN1. This interface is preconfigured with the IP address 192.168.1.1.

To mount the appliance:


1. Place the wall-mount sticker on the wall and drill two holes for the screws.



2. Insert the 2 screw anchors in the wall.

3. Attach the 2 screws in the accessory kit (M4*6 mm) to the wall.
4. Mount the appliance and verify the 2 screws are fastened well to the appliance.

Bottom of the appliance



Key	Item	Description
1	Holes on the bottom of the appliance	Attach screws here
2	Rubber feet	Attached to the bottom of the appliance

Connecting the Cables

1. Connect the appliance to the power supply and turn the power switch to on.
2. When the appliance is turned on, the Power LED on the front panel lights up in red for a short period.

The LED then turns blue and starts to blink. This shows a boot is in progress and firmware is being installed.

When the LED turns a solid blue, the appliance is ready for login.



Note - The LED is red if there is an alert or error.

3. Connect the standard network cable to the LAN1 port on the appliance front panel and to the network adapter on your PC.
4. **If you use an external modem:**

Connect the Ethernet cable to the WAN port on the appliance back panel and plug it into your external modem or router's PC/LAN network port. The Internet LED on the appliance front panel lights up when the Ethernet is connected.

5.  **Note** - Wait 10 seconds between power cycles (off and on).

First Time Deployment Options

There are different options for first time deployment of your gateways:

- *"Using the First Time Configuration Wizard" on page 13*
- *"Zero Touch Cloud Service" on page 31*
- *"USB Drive" on page 33*

Using the First Time Configuration Wizard

Configure the Quantum Spark Appliance with the First Time Configuration Wizard.

To close the wizard and save configured settings, click **Quit**.

 **Note** - In the First Time Configuration Wizard, you may not see all the pages described in this guide. The pages that show in the wizard depend on your appliance model and the options you select.

Starting the First Time Configuration Wizard

To configure the 2580 Appliance for the first time after you complete the hardware setup, use the First Time Configuration Wizard.

If you do not complete the wizard because of one of these conditions, the wizard will run again the next time you connect to the appliance:

- The browser window is closed.
- The appliance is restarted while you run the wizard.

After you complete the wizard, you can use the WebUI (web user interface) to change settings configured with the First Time Configuration Wizard and to configure advanced settings.

To open the Appliance WebUI, enter one of these addresses in a web browser:

- `http://my.firewall`
- `https://192.168.1.1:4434`

If a security warning message shows, confirm it and continue.

The **First Time Configuration Wizard** starts.

Welcome

The **Welcome** page introduces the product and shows the name of your appliance.

You can connect to the Zero Touch server to fetch settings automatically from the cloud.

To change the language of the WebUI application:

Select the language link at the top of the page.



Note - Only English is allowed as the input language.

Zero Touch

Zero Touch enables a gateway to automatically fetch settings from the cloud when it is connected to the internet for the first time.



Note - You cannot use Zero Touch if you connect to the internet with a proxy server.

If the gateway connects to the internet through DHCP, the gateway will fetch the Zero Touch settings without any additional action. If no DHCP service is available, you must run the First Time Configuration Wizard, configure the **Internet Connection** settings, and then fetch the settings from the Zero Touch server.

To connect to the Zero Touch server:

1. In the **Welcome** page, click **Fetch Settings from the cloud**.
2. In the window that opens, click **OK** to confirm that you want to proceed.
3. The **Internet connection** page opens. Configure your Internet connection and click **Connect**.
4. The **Fetching settings from the cloud** window opens and shows the **Connecting to the service provider** status. This process may take several minutes.
5. If you fail to connect, an error message appears. Possible errors include:
 - Internet connection is not configured correctly.
 - Internet connection is through a proxy server.
 - Zero Touch is already running.
 - Zero Touch service already completed.
 - The First Time Configuration Wizard already completed.

- Zero Touch service is disabled.

Where applicable, click **Retry now** to connect again.

6. After you connect to the server, the settings are automatically downloaded and installed. The status is shown in the **Fetching settings from the cloud** window. It may take several minutes until the installation is complete.
7. Click **Finish**.

 **Note** - If a collision is detected between an internal network (LAN) and an IP returned using DHCP (WAN), the conflicting LAN address is changed automatically. If a colliding LAN IP address is changed, a message appears in the system logs.

When you reconnect to the WebUI or click **Refresh**, the browser opens to show the status of the installation process.

After the gateway downloads and successfully applies the settings, it does not connect to the Zero Touch server again.

Authentication Details

In the **Authentication Details** page, enter the required details to log in to the appliance WebUI, or if the wizard terminates abnormally:

- **Administrator Name** - We recommend that you change the default "admin" login name of the administrator. The name is case sensitive.
- **Password** - A strong password has a minimum of 8 characters with at least one capital letter, one lower case letter, and a special character. Use the **Password strength** meter to measure the strength of your password.

 **Note** - The meter is only an indicator and does not enforce creation of a password with a specified number of character or character combination. To enforce password complexity, click the checkbox.

- **Confirm Password** - Enter the password again.
Optional - Select to **Enforce the password history mechanism**.
- Enter the Administrator **Email**. Used to receive Notifications and for Two-Factor Authentication.
- Enter the Administrator **Phone number**. Used to receive Notifications and for Two-Factor Authentication.
- **Country** - Select a country from the list (**for wireless network models only**).

 **Note** - The country code selection is for non-US models only and is not available for all US models. Per FCC regulation, all WiFi products marketed in the US must be fixed to US operation channels only.

The country where the license is set determines the wireless frequency and parameters, as the regulations vary according to region.

If you are using a trial license, only **basic radio settings**, are allowed in all zones. A warning that selected wireless radio settings are not applied shows on the **Summary** page and also on the **Device > License** page. For more information on basic wireless radio settings, see [sk159693](#).

If you select a country and install a valid license, but the wireless region of the device does not match the selected country, a warning message shows and you must edit the country information. When the country and wireless region match, you see the full settings.

Appliance Date and Time Settings

In the **Appliance Date and Time Settings** page, configure the appliance's date, time, and time zone settings manually or use the Network Time Protocol option.

If you select the option **Set the time manually**, the appliance uses the date and time from your computer as the initial values. If necessary, change the time zone setting to show your correct location. Daylight Savings Time is automatically enabled by default. You can change this in the WebUI application on the **Device > Date and Time** page.

- **Date** - The date on your computer appears by default. If required, set a different date.
- **Time** - The time on your computer appears by default. If required, set a different time.
- **Time Zone** - The time zone on your computer appears by default. If required, select a time zone setting to reflect your exact location.
- **Primary NTP server** - The IP or host name of the primary NTP server. The default server is `ntp.checkpoint.com`
- **Secondary NTP server** - The IP or host name of the secondary NTP server. The default server is `ntp2.checkpoint.com`

Appliance Name

In the **Appliance Name** page, enter a name to identify the appliance, and enter a domain name (optional).

When the gateway performs DNS resolving for a specified object's name, the domain name is appended to the object name. This lets hosts in the network look up hosts by their internal names.

Security Policy Management

In the **Security Policy Management** page, select how to manage security settings:

- **Central management** - A remote Security Management Server manages the Security Gateway in SmartConsole with a network object and security policy.
- **Local management** - The appliance uses a web application to manage the security policy. After you configure the appliance with the First Time Configuration Wizard, the default security policy is enforced automatically. With the appliance WebUI, you can configure the Software Blades you activated and fine tune the security policy.

This Getting Started Guide describes how to configure both locally and centrally managed deployments.

Internet Connection

On the **Internet Connection** page, configure your Internet connectivity details or select **Configure Internet connection later**.

To configure Internet connection now:

1. Select **Configure Internet connection now**.
 2. From the **Connection type** drop down list, select the protocol used to connect to the Internet.
 3. Enter the fields for the selected connection protocol. The information you must enter is different for each protocol. You can get it from your Internet Service Provider (ISP).
 - **Static IP** - A fixed (non-dynamic) IP address.
 - **DHCP** - Dynamic Host Configuration Protocol (DHCP) automatically issues IP addresses within a specified range to devices on a network. This is a common option when you connect through a cable modem.
 - **PPPoE (PPP over Ethernet)** - A network protocol for encapsulating Point-to-Point Protocol (PPP) frames inside Ethernet frames. It is used mainly with DSL services where individual users connect to the DSL modem over Ethernet and Metro Ethernet networks. Enter the **ISP login user name** and **ISP login password**. **Note** - In the First Time Configuration Wizard, only dynamic IP is supported.
 - **PPTP** - The Point-to-Point Tunneling Protocol (PPTP) implements virtual private networks. PPTP uses a control channel over TCP and a GRE tunnel operating to encapsulate PPP packets.
 - **L2TP** - Layer 2 Tunneling Protocol (L2TP) is a tunneling protocol used to support virtual private networks (VPNs). It does not provide any encryption or confidentiality. It relies on an encryption protocol that it passes within the tunnel to provide privacy.
 - **Cellular** - This is only for appliances with an internal LTE modem. Both SIM cards are used for the internet connection with a failover between them.
 - **Cellular Modem** - This does not apply to Wired models. Connect to the Internet with a cellular modem to the ISP through a 3G or 4G network. For this option, select the USB/Serial option in the Interface name.
-  **Note** - Only one cellular modem is supported. Appliances with an internal LTE modem do not support an external USB modem. Only customers with an approved RFE will be supported with the external modem specified in the RFE.
- **Bridge** - Connects multiple network segments at the data link layer (Layer 2).

- **DNS Server** (Static IP and Bridge connections) - Enter the DNS server address information in the relevant fields. For DHCP, PPPoE, PPTP, L2TP, Cellular, and the DNS settings are supplied by your service provider. You can override these settings later in the WebUI application, under **Device > DNS**.

We recommend that you configure the DNS as the appliance needs to perform DNS resolving for different functions. For example, to connect to Check Point User Center during license activation or when Application Control, Web Filtering, Anti-Virus, or Anti-Spam services are enabled.

To test your ISP connection status:

Click **Connect**.

The appliance connects to your ISP. Success or failure shows at the bottom of the page.

Local Network

In the **Local Network** page, select to enable or disable switch on LAN ports and configure your network settings. By default, they are enabled. You can change the IP address and stay connected as the appliance's original IP is kept as an alias IP until the first time you boot the appliance.

Tell me about the fields...

- **Enable switch on LAN ports** - Aggregates all LAN ports to act as a switch with one IP address for the switch. If this option is disabled (checkbox is cleared), the local network is defined as LAN1 only.
- **Network name** - Enter the network name.
- **IP address** - You can modify the IP address and maintain connectivity. The appliance's original IP is kept as an alias IP to maintain connectivity until the wizard is completed.
- **Subnet mask** - Enter the subnet mask.
- **DHCP server and range fields** - DHCP is enabled by default with a default network range. Make sure to set the appropriate range and do not include predefined static IPs in your network.
- **Exclusion range** - Set the exclusion range for IP addresses that are not defined by the DHCP server. Define the range of IP addresses that the DHCP excludes when IP addresses are assigned in the network. The appliance's IP address is automatically excluded from the range. For example, if the appliance IP is 1.1.1.1 the range also starts from 1.1.1.1, but excludes its own IP address.

 **Important** - If you choose to disable the switch on LAN ports (clear the checkbox), make sure your network cable is placed in the LAN1 port. Otherwise, connectivity will be lost when you click **Next**.

Administrator Access

In the **Administrator Access** page, configure if administrators can use the appliance from a specified IP address or any IP address.

To configure administrator access:

1. Select the sources from where administrators are allowed access:
 - **LAN** - All internal physical ports.
 - **Trusted wireless** - A known wireless network.
 - **VPN** - Using encrypted traffic through VPN tunnels from a remote site or using a remote access client.
 - **Internet** - Clear traffic from the Internet (not recommended).
2. Select the IP address from which the administrator can access the appliance:
 - **Any IP address**.
 - **Specified IP addresses only** - Select this option to let administrators access the appliance from a specified IP address or network. Click **New** to configure the IP address information.
 - **Specified IP addresses from the Internet and any IP address from other sources** - Select this option to allow administrator access from the Internet from specific IP addresses only and access from other selected sources from any IP address. This option is the default.

To specify IP addresses:

1. Click **New**.
2. In the IP Address Configuration window, select an option:
 - **Specific IP address** - Enter the **IP address** or click **Get IP from my computer**.
 - **Specific network** - Enter the **Network IP** address and **Subnet mask**.
3. Click **Apply**.

Appliance Registration

The appliance can connect to the [Check Point User Center](#) with its credentials to pull the license information and activate the appliance.

If you have Internet connectivity configured:

Click **Activate License**.

You are notified that you successfully activated the appliance and you are shown the status of your license for each Software Blade.

If you are working offline while configuring the appliance:

1. From a computer with authorized access to the [Check Point User Center](#), follow *one* of these procedures:

 **Note** - If you do not have a User Center account, select **Create a new User Center account**.

- **Use your User Center account**

- a. Log in to your User Center account.
- b. Select the specified container of your appliance.
- c. From the **Product Information** tab, click **License > Activate**.

This message appears: "*Licenses were generated successfully*".

- d. Click **Get Activation File** and save the file locally.

- **Register your appliance**

- a. Go to: <https://smbregistration.checkpoint.com>
- b. Enter your appliance details and click **Activate**.

This message appears: "*Licenses were generated successfully*".

- c. Click **Get Activation File** and save the file locally.

2. In the **Appliance Activation** page of the First Time Configuration Wizard, click **Offline**.

The **Import from File** window opens

3. Browse to the activation file you downloaded and click **Import**. The activation process starts.

You are notified that you successfully activated the appliance and you are shown the status of your license for each blade.

If there is a proxy between your appliance and the Internet, you must configure the proxy details before you can activate your license.

To configure the proxy details:

1. Click **Set proxy**.
2. Select **Use proxy server** and enter the proxy server **Address** and **Port**.
3. Click **Apply**.
4. Click **Activate License**.

You are notified that you successfully activated the appliance and you are shown the status of your license for each blade.

To postpone appliance registration and get a 30-day trial license:

1. Click **Next**.

The License activation was not complete notification message is shown.

2. Click **OK**.

The appliance uses a 30-day trial license for all blades. You can register the appliance later in the WebUI from the **Device > License** page.

If your device is not paired with a User Center account, you must create an account or ask your company administrator to create one for you.

To create a new User Center account (for Locally Managed appliances only):

1. Click **Activate License**.

The **Appliance Registration** window opens.

2. Select **Create a new User Center account** and click **Next**.

3. In the new window, enter:

- **First name**
- **Last Name**
- **Email**. You must enter this a second time to confirm.
- **Company** - This is the Account Name to which the appliance is paired.

4. Click **Next**.

The **Software Blades Activation** page opens.

Security Management Server Authentication

For Centrally Managed appliances only:

When you select central management as your security policy management method, the **Security Management Server Authentication** page opens.

Select an option to authenticate trusted communication with the Security Management Server:

- **Initiate trusted communication securely by using a one-time password** - The one-time password is used to authenticate communication between the appliance and the Security Management Server securely.

Enter a **one-time password** and confirm it. This password is only used for establishing the initial trust. When established, trust is based on security certificates.

 **Important** - This password must be identical for the Secure Communication authentication one-time password configured for the appliance object in the SmartConsole of the Security Management Server.

- **Initiate trusted communication without authentication (not secure)** - Use this option only if there is no risk of malicious behavior (for example, when in a lab setting).
- **Configure one-time password later** - Set the one-time password at a different time using the WebUI application.

Security Management Server Connection

For Centrally managed appliances only:

After you set a one-time password for the Security Management Server and the appliance, you can connect to the Security Management Server to establish trust between the Security Management Server and the appliance.

To connect to the Security Management Server, select one of these:

- **Connect to the Security Management Server now.**
- **Connect to the Security Management Server later.**

If you select to connect now, enter the data for these fields:

- **Management address** - Enter the IP address or host name of the Security Management Server.
- **Connect** - When you successfully connect to the Security Management Server, the security policy will automatically be fetched and installed.
- If the Security Management Server is deployed behind a 3rd-party NAT device, select **Always use the above address to connect to the Security Management Server**. Manually enter the IP address or the host name of the appliance should connect to reach the Security Management Server.

If you enter an IP address, it will override the automatic mechanism that determines the routable IP address of the Security Management Server for each appliance.

When you provide a host name, it will be saved, and the Security Gateway will automatically update the resolved IP address if any changes occur. You can edit this configuration later in the **Home > Security Management** page of the WebUI.

If you do not select this checkbox and you use a host name to fetch the policy, when the policy is fetched, the Security Management Server IP is set to the IP address in the policy.

Select where to send logs:

- **Send logs to same address** - The logs are sent to the IP address entered on this page for the Security Management Server.
- **Send logs to** - Enter the IP address of a log server.
- **Send logs according to policy** - The logs are sent according to the log server definitions that are defined in the policy.

Software Blade Activation

Select the Software Blades to activate on this appliance.

QoS (bandwidth control) can only be activated from the WebUI after completing the First Time Configuration Wizard.

Summary

The **Summary** page shows the details of the elements configured with the First Time Configuration Wizard.

Click **Finish** to complete the First Time Configuration Wizard.

The WebUI opens on the **Home > System** page.

To back up the system configuration in the WebUI:

Go to **Device > System Operations > Backup**.

Zero Touch Cloud Service

The Zero Touch Cloud Service lets you easily manage the initial deployment of your gateways in the [Check Point Zero Touch Portal](#).

Zero Touch enables a gateway to automatically fetch settings from the cloud when it is connected to the internet for the first time.

For more information on how to use Zero Touch, see [sk116375](#).

 **Note** - If you already used the First Time Configuration Wizard to configure your appliance, you cannot use the Zero Touch Cloud service. If you start the First Time Configuration Wizard while the Zero Touch settings are being installed, the installation process terminates.

If the gateway connects to the internet via DHCP, the gateway will fetch the Zero Touch settings without any additional action. If no DHCP service is available, you must run the First Time Configuration Wizard, configure the Internet Connection settings, and then fetch the settings from the Zero Touch server.

To connect to the Zero Touch server from the First Time Configuration Wizard:

1. In the **Welcome** page of the First Time Configuration Wizard, click **Fetch Settings from the cloud**.
2. In the window that opens, click **Yes** to confirm that you want to proceed.
3. The **Internet connection** page of the First Time Configuration Wizard opens. Configure your Internet connection and click **Connect**.

The settings are automatically downloaded and installed.

A new window opens and shows the installation status. It may take several minutes until the installation is complete.

When you reconnect to the appliance WebUI or click **Refresh**, you may see one of these:

- **Login** page - This means the process ended successfully and your settings are installed.
- **Welcome** page of the First Time Configuration Wizard - The process is still running. The settings are installing or they do not exist in the cloud.

 **Note** - If you click **Next** on the **Welcome** page, the Zero Touch settings installation process terminates.

- **Page not found** - The appliance local IP address may have been changed by the cloud settings installation. Try `http://my.firewall` or consult your administrator for the new local IP address.

After the gateway downloads and successfully applies the settings, it does not connect to the Zero Touch server again.

USB Drive

The configuration file lets you configure more settings and parameters than are available in the First Time Configuration Wizard

You can deploy configuration files only on these appliances:

- You did not run the First Time Configuration Wizard yet.
- You restored an appliance to factory defaults.

To use rapid deployment files through a USB stick or an SD card:

1. On your computer, in plain-text editor, create a file named `autoconf.clish`.
2. In this file, write the applicable Gaia Clish commands, with each command in a separate line.

Refer to the [R82.00.X Quantum Spark Appliances CLI Reference Guide](#).


3. Save this file in the UNIX format.
4. Format the USB drive or SD card in FAT32.
5. Copy this file to the USB drive.
6. Power off the Quantum Spark appliance.
7. Insert the USB stick into the USB 3.0 port in the Quantum Spark appliance.
8. Optional: To see more information, you can connect to the console port on the Quantum Spark appliance.
9. Power on the Quantum Spark appliance.
10. The appliance:
 - a. Starts.
 - b. Automatically mounts the USB drive.
 - c. Searches the root directory for this configuration file.
 - d. Executes the Gaia Clish commands from this configuration file.
11. Wait for the applicable LEDs to light up on the front panel.

See ["Front Panel" on page 35](#).
12. Power off the Quantum Spark appliance.
13. Remove the USB drive from the Quantum Spark appliance.
14. Power on the Quantum Spark appliance.

Appliance Diagrams and Specifications


This structure describes the different features in the front and back panels of these appliances:

Wired



Front Panel

This section describes the Front Panel on 2580 Appliances - LEDs, ports, and buttons.



Note - There is only one set of LEDs. These LEDs show different colors depending on what activity is occurring.

Key	Item	Description
1	LEDs	From top to bottom:  Power redundancy - Shows the status of the two internal PSUs. Single red LED. - The two Power Supplies are active - Off - Failure in one of the Power Supplies - On  Storage memory - SSD storage memory. Bi-color blue/red displays SSD status. - No SSD access - Blue Off, Red Off - SSD failure - Blue Off, Red On  Management - See below  Internet - No internet connection - Off - Connecting to the internet - Blinking blue - Connected - Blue - Connection failure - Blinking red  Power/Status - Normal operation - Solid blue - Boot in progress or installing firmware - Blinking blue - Error/Alert - Red
2	Console	There are two console ports for the serial console cable: USB Type-C and RJ45. USB Type-C has priority when both are connected. Baud rate: 115200.

Key	Item	Description
3	DMZ ports	The DMZ is a combo port of SFP and RJ45 (on the right). Only one can operate a time once plugged in and connected. The RJ45 port supports 10 / 100 MbE and 1 / 10 GbE. The SFP port supports only 1G / 10 GbE.  Note - For information about supported SFP transceivers, see sk92755.
4	LAN ports 3-10	Support 10 /100 / 1000 MbE
5	LAN ports 1-2	RJ45 2.5Gps ports and also support 1Gps.
6	WAN ports	The WAN port is a combo port of SFP and RJ45 (on the right). Only one can operate a time once plugged in and connected. The RJ45 port supports 10 / 100 MbE and 1/10 GbE. The SFP port supports only 1/10 GbE.  Note - For information about supported SFP transceivers, see sk92755.
7	USB3.0	USB port 3.0 for software download.
8	Console	There are two console ports for the serial console cable: USB Type-C and RJ45. USB Type-C has priority when both are connected. Baud rate: 115200
9	Factory Default	Press the button continuously for 12 seconds to restore the appliance to its factory default. All user parameters previously configured are removed.
10	Reset	Short press resets the system but does not remove any user parameters.

Management LED

The **Management LED** shows the status of the retries mechanism:

Action	Management LED Activity
Zero Touch is running.	Blinks red (slowly)
Successfully connected to Zero Touch Cloud Server and saved the deployment script.	Blinks red (rapidly)
Zero Touch process is completed. SMP activation is not needed.	Off
Activation sleeping time.	Blinks blue (slowly)
Reactivation.	Blinks blue (rapidly)
SMP is connected.	Solid blue
SMP mode is off.	off
Gateway failed to connect to the SMP and will exit from the retry script.	Solid red

Wait times before retry:

Failure	Waiting Time
1st	2 minutes
2nd	4 minutes
3rd	8 minutes
4th	16 minutes
Subsequent	Retries every 16 minutes until Cloud Services are successfully activated

Network LEDs

The table below describes the network LEDs (RJ45 WAN and LAN ports and the SFP).

Each port uses a bi-color LED (green/amber) to reflect the link/activity and speed.

This also applies to the DMZ port.

Speed	Link	Activity	Link/Act LED1 Left	Speed LED2 Right
No link			No LED	No LED
1G	Yes	No	Solid Green	Solid Amber
1G	Yes	Yes	Blinking Green	Solid Amber
100M	Yes	No	Solid Green	No LED
100M	Yes	Yes	Blinking Green	No LED
10M	Yes	No	Solid Green	No LED
10M	Yes	Yes	Blinking Green	No LED

2xRJ45 2.5GbE ports

Two bi-color (green and amber) LEDs per port


Speed	Link	Activity	Link/Act LED1 Left	Speed LED2 Right
No link			No LED	No LED
2.5G	Yes	No	Solid Green	Solid Amber
2.5G	Yes	Yes	Blinking Green	Solid Amber
1G	Yes	No	Solid Green	No LED
1G	Yes	Yes	Blinking Green	No LED
100M	Yes	No	Solid Green	No LED
100M	Yes	Yes	Blinking Green	No LED
10M	Yes	No	Solid Green	No LED
10M	Yes	Yes	Blinking Green	No LED

WAN / DMZ RJ45 and SFP 10GbE port

Speed	Link	Activity	Link/Act LED1 Left	Speed LED2 Right
No link			No LED	No LED
10G	Yes	No	Solid Green	Solid Amber
10G	Yes	Yes	Blinking Green	Solid Amber
1G	Yes	No	Solid Green	Solid Green
1G	Yes	Yes	Blinking Green	Solid Green
100M	Yes	No	Solid Green	No LED
100M	Yes	Yes	Blinking Green	No LED
10M	Yes	No	Solid Green	No LED
10M	Yes	Yes	Blinking Green	No LED

Back Panel


Wired



Key	Item	Description
1	DC 12V Power cord sockets	Plug the power adapter cords in here.
2	Power LEDs	Two LEDS for power indication.
3	Fan	Cooling function.
4	Power on/off switch	0 - Off 1 - On
6	Ground screw	Protective grounding. For more information, refer to the "Health and Safety Information" on page 42.

Side Panel

Side 1



Key	Item	Description
1	SD slot	Insert micro-SD card here.

SD Card Notes:

- Micro-SD card supports the format `ext4`, up to 256GB size.
- Insert or remove SD card only when the appliance is powered down.
- While inserting the micro-SD card, make sure the golden pins are facing upward:



Health and Safety Information

Read these warnings before setting up or using the appliance.

-  **Warning** - Do not block air vents. A minimum 1/2 inch (1,27 cm) clearance is required.
-  **Warning** - This appliance does not contain any user-serviceable parts. Do not remove any covers or attempt to gain access to the inside of the product. Opening the device or modifying it in any way has the risk of personal injury and will void your warranty. The following instructions are for trained service personnel only.

Power Supply Information

The appliance contains an embedded power supply AC-DC. The 2580 appliances contain a dual power supply.

To prevent damage to any system, it is important to handle all parts with care.



CAUTION: TO DISCONNECT POWER, REMOVE ALL POWER CORDS FROM UNIT.

注意：要断开电源，请将所有电源线从本机上拔下。

WARNUNG: Wenn Sie das Gerät zwecks Wartungsarbeiten vom Netz trennen müssen, müssen Sie beide Netzteile abnehmen.

ATTENTION: DÉBRANCHER TOUS LES CORDONS D'ALIMENTATION POUR DÉCONNECTER L'UNITÉ DU SECTEUR.

IMPORTANT SAFETY INSTRUCTIONS: Basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use this product near water for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- This equipment is not suitable for use in locations where children are likely to be present.
- Make sure to connect the power cord to a socket-outlet with a grounded connection.
- Never open the equipment. For safety reasons, the equipment should be opened only by a qualified skilled person authorized by Check Point.

Connecting Earth Ground to Equipment

 **Warning** - The equipment has a separate protective earthing terminal on the chassis that must be permanently connected to earth ground to adequately ground the chassis and protect the operator from electrical hazards.

 **Caution** - Before starting the equipment installation, ensure that a service technician has securely attached the grounding lug to the provided grounding cable.

To connect earth ground to equipment:

1. Connect one end of the grounding cable to a proper earth ground.
2. Place the ground lug attached to the ground cable over the protective earthing terminal.
3. Secure the grounding lug to the protective earthing terminal with washers and screws
4. Dress the grounding cable and ensure that it does not touch or block access to other components.

 **Warning** - Before powering on the equipment, connect the frame of the equipment to earth. For the earthing wire, green and yellow insulation is required and the cross-sectional area of the conductor must be more than 0.75mm^2 or 18 AWG.

 **Warning** - The protective earthing terminal with washers and screws where a screw is threaded into it should not be less than twice the pitch of the screw thread, at least 3.5mm diameter; star washers or spring washers can be used.

 **Warning** - After power is off and disconnected from the equipment, then disconnect the frame of the equipment to earth.

Power Supply Information

This product is intended to be supplied by a UL listed (Certificate) power supply, output rated 12V 5A minimum, Tma 40 degree C minimum. The altitude of operation of the power supply should comply with the altitude of the installation area. If you need further assistance, contact manufacture or brand owner further information.



Caution - Risk of explosion if the battery is replaced by an incorrect type.



Warning - This is a class 1 Laser product. Use only IEC 60825-1 certified Optical Fiber Transceiver with minimum operating temperature at 75 degree C.(for EU)
Laser Class 1 optical transceiver shall be used only. (for UL)

For North America only

Warning message for using product in ITE environment:

Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.

For California:

Perchlorate Material - special handling may apply. See

<http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

The foregoing notice is provided in accordance with California Code of Regulations Title 22, Division 4.5, Chapter 33. Best Management Practices for Perchlorate Materials. This product, part, or both may include a lithium manganese dioxide battery which contains a perchlorate substance.

Proposition 65 Chemical

Chemicals identified by the State of California, pursuant to the requirements of the California Safe Drinking Water and Toxic Enforcement Act of 1986, California Health & Safety Code s. 25249.5, et seq. ("Proposition 65"), that is "known to the State to cause cancer or reproductive toxicity." See <http://www.calepa.ca.gov>.

WARNING:

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling.

Product Disposal

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a distributor for designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office or your household waste disposal service.

Declaration of Conformity

Manufacturer's Name:	Check Point Software Technologies Ltd.
Manufacturer's Address:	5 Shlomo Kaplan Street, Tel Aviv 67897, Israel
Regulated Models:	T92
Marketing Models:	SG2580
Product Options:	Wired only
Date First Applied:	April 2025, Tel Aviv, Israel

Declares under our sole responsibility, that the products conform to the following Product Specifications:

Certification	Type
EN 55032:2015/A11:2020, Class B EN 55035:2017/A11:2020 EN IEC 61000-3-2:2019/A1:2021 EN 61000-3-3:2013/A2:2021 AS/NZS CISPR 32:2015 AMD 1:2020 BS EN 55032:2015+A11:2020, Class B BS EN 55035:2017+A11:2020 BS EN IEC 61000-3-2:2019+A1:2021 BS EN 61000-3-3:2013+A2:2021 IEC 61000-4-2 Ed. 2.0:2008 IEC 61000-4-3 Ed. 4.0:2020 IEC 61000-4-4 Ed. 3.0:2012 IEC 61000-4-5 Ed. 3.1:2017 IEC 61000-4-6 Ed. 5.0:2023 IEC 61000-4-8 Ed. 2.0:2009 IEC 61000-4-11 Ed. 3.0:2020 47 CFR FCC Part 15 Subpart B ICES-003 Issue 7 : October 2020 ANSI C63.4 : 2014 VCCI-CISPR 32 : 2017	EMI (Electromagnetic Interference) and EMC (Electromagnetic Compatibility)
CE LVD EN62368-1 CB IEC /EN62368-1 2nd and 3rd edition. AS/NZS 62368.1:2022 CSA C22.2 No. 62368-1:2019 GB 4943.1-2022 EN IEC 62368-1:2020+A11:2020, BS EN IEC 62368-1:2020+A11:2020 J62368-1 (2023) National standard SASO-IEC 62368-1:2020 UL 62368-1:2019 KC 62368-1 (2021-08) UL62368-1	Electrical Safety

Testing labs

Prodigy Technology Consultant Co., Ltd.	No. 12, Gong 7th Rd., Linkou District, New Taipei City 24450, Taiwan.
DEKRA Testing and Certification Co., Ltd.	No. 85, Wenlin St., Linkou Dist., New Taipei City, 244017, Taiwan.

European Union (EU) Electromagnetic and Safety Compatibility Directive

This product is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directives 2004/108/EC and 2014/30/EU. This product is in conformity with Low Voltage Directives 2006/95/EC and 2014/35/EU. This product complies with the requirements in the Council Directives 2006/95/EC and 2014/35/EU relating to electrical equipment designed for use within certain voltage limits and the Amendment Directive 93/68/EEC.

Federal Communications Commission (FCC) Notice (US)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

Compliance Information

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Department Compliance Statement

This device complies with Industry Canada ICES-003 rules.

Japan Class B Compliance Statement

This is a Class B product based on the standard of the Voluntary Control Council for Interference (VCCI).

If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

この装置は、クラスB 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

Physical and environmental reliability	Description
Operating Conditions	Vibrations and Shock Based on EN 300 019-2-3. Temperature: 0°C ~ 40°C
Storage Conditions	Temperature: (-40)°C ~ 60°C. Humidity: 95%, non-condensed. Vibrations and Shock based on EN 300 019-2-1.
Transportation Conditions	Temperature: (-40)°C ~ 85°C. Humidity: 95%, non-condensed. Vibrations and Shock based on EN 300 019-2-2.

Informations relatives à la santé et à la sécurité

Avant de mettre en place ou d'utiliser l'appareil, veuillez lire ces avertissements.

-  **Avertissement** : ne pas obturer les aérations. Un dégagement minimum de 1,27 cm (1/2 pouce) est nécessaire.
-  **Avertissement** : cet appareil ne contient aucune pièce remplaçable par l'utilisateur. Ne retirez aucun couvercle et n'essayez pas d'accéder à l'intérieur du produit. L'ouverture ou la modification de l'appareil peut entraîner un risque de blessure et invalidera la garantie. Les instructions suivantes sont réservées à un personnel de maintenance formé.

Information pour l'alimentation

L'appareil contient un bloc d'alimentation intégré AC-DC. Les appareils 2580 sont dotés d'une double alimentation.

Pour éviter d'endommager tout système, il est important de manipuler les éléments avec soin.



CAUTION: TO DISCONNECT POWER, REMOVE ALL POWER CORDS FROM UNIT.

注意：要断开电源，请将所有电源线从本机上拔下。

WARNUNG: Wenn Sie das Gerät zwecks Wartungsarbeiten vom Netz trennen müssen, müssen Sie beide Netzteile abnehmen.

ATTENTION: DÉBRANCHER TOUS LES CORDONS D'ALIMENTATION POUR DÉCONNECTER L'UNITÉ DU SECTEUR.

CONSIGNES DE SÉCURITÉ IMPORTANTES : Lors de l'utilisation de votre équipement téléphonique, des précautions de base doivent toujours être prises afin de réduire les risques d'incendie, d'électrocution et de blessures, notamment celles qui suivent.

- Ne pas utiliser ce produit à proximité de l'eau, par exemple près d'une baignoire, d'un lavabo, d'un évier de cuisine ou d'un bac à linge, dans un sous-sol humide ou près d'une piscine.
- N'utiliser que le cordon d'alimentation et les piles indiqués dans ce manuel. Ne pas jeter les piles au feu. Elles risquent d'exploser. Vérifier les réglementations locales pour d'éventuelles instructions spéciales concernant la mise au rebut.
- Cet appareil ne doit pas être utilisé dans des lieux où des enfants sont susceptibles d'être présents.
- Veillez à brancher le cordon d'alimentation sur une prise de courant avec mise à la terre.
- Ne jamais ouvrir l'appareil. Pour des raisons de sécurité, l'équipement ne doit être ouvert que par une personne qualifiée et autorisée par Check Point.

Mise à la terre de l'équipement

 **Avertissement** : L'appareil est équipé d'une borne de mise à la terre séparée sur le châssis, qui doit être en permanence connectée à la terre afin d'assurer la mise à la terre du châssis de manière adéquate et de protéger l'opérateur contre les risques électriques.

 **Attention** : Avant de commencer l'installation de l'équipement, assurez-vous qu'un technicien a bien fixé la cosse de mise à la terre au câble de mise à la terre fourni.

Pour mettre à la terre l'équipement :

1. Connectez une extrémité du câble de mise à la terre à une prise de terre appropriée.
2. Placez la cosse de mise à la terre attachée au câble de mise à la terre sur la borne de mise à la terre.
3. Fixer la cosse de mise à la terre à la borne de mise à la terre de protection à l'aide de rondelles et de vis.
4. Recouvrez le câble de mise à la terre et veillez à ce qu'il ne touche pas ou ne bloque pas l'accès à d'autres composants.

 **Avertissement** : Avant de mettre l'appareil sous tension, mettez le châssis de l'appareil à la terre. Pour le câble de mise à la terre, une isolation verte et jaune est requise, et la section du conducteur doit être supérieure à 0,75 mm² ou 18 AWG.

 **Avertissement** : La borne de mise à la terre avec les rondelles et les vis dans lesquelles une vis est vissée ne doit pas être inférieure à deux fois le pas du filetage de la vis, soit un diamètre d'au moins 3,5 mm ; des rondelles en étoile ou des rondelles à ressort peuvent être utilisées.

 **Avertissement** : Après avoir coupé l'alimentation et débranché l'appareil, déconnectez le châssis de l'appareil de la terre.

Information pour l'alimentation

Ce produit est destiné à être alimenté par un bloc d'alimentation homologué UL (certificat), avec une sortie de 12V 5A minimum, T_{ma} 40 degrés C minimum. L'altitude de fonctionnement de l'alimentation électrique doit être conforme à l'altitude de la zone d'installation. Si vous avez besoin d'aide, contactez le fabricant ou le propriétaire de la marque pour plus d'informations.



Attention : risque d'explosion si la batterie est remplacée par un type de batterie incorrect.



Avertissement : Cet appareil est un produit laser de classe 1. N'utilisez que des émetteurs-récepteurs à fibre optique certifiés IEC 60825-1 avec une température minimale de fonctionnement de 75 degrés C (pour l'UE).

Seul un émetteur-récepteur optique laser de classe 1 doit être utilisé. (pour UL)

Pour l'Amérique du Nord uniquement

Message d'avertissement concernant l'utilisation du produit dans un environnement ITE :

Convient à une installation en Chambre Informatique conformément à l'Article 645 du National Electrical Code et au NFPA 75.

Pour la Californie :

Matériau perchloraté : manipulation spéciale potentiellement requise. Voir

<http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

L'avis suivant est fourni conformément au California Code of Regulations, titre 22, division 4.5, chapitre 33. Meilleures pratiques de manipulation des matériaux perchloratés. Ce produit, cette pièce ou les deux peuvent contenir une pile au dioxyde de lithium manganèse, qui contient une substance perchloratée.

Proposition 65 - Produits chimiques

Produits chimiques identifiés par l'État de Californie, conformément aux exigences du California Safe Drinking Water and Toxic Enforcement Act de 1986, California Health & Safety Code s. 25249.5, et seq. (« Proposition 65 »), qui sont « considérés par l'État comme pouvant provoquer le cancer ou avoir des effets toxiques sur la reproduction ». Voir

<http://www.calepa.ca.gov>.

AVERTISSEMENT :

La manipulation de ce cordon vous expose au contact du plomb, un élément reconnu par l'état de Californie pour être cancérigène, provoquer des malformations à la naissance et autres dommages relatifs à la reproduction. Se laver les mains après toute manipulation.

Mise au rebut du produit

Ce symbole apposé sur le produit ou son emballage signifie que le produit ne doit pas être mis au rebut avec les autres déchets ménagers. En revanche, il est de votre responsabilité de vous débarrasser de vos déchets d'équipement en les remettant à un distributeur ou à un point de collecte désigné pour le recyclage des déchets d'équipements électriques et électroniques. Le fait de séparer vos équipements lors de la mise au rebut, et de les recycler, contribue à préserver les ressources naturelles et s'assure qu'ils sont recyclés d'une façon qui protège la santé de l'homme et l'environnement. Pour obtenir plus d'informations sur les lieux où déposer vos équipements mis au rebut, veuillez contacter votre municipalité ou le service de gestion des déchets.

Déclaration de conformité

Nom du fabricant :	Check Point Software Technologies Ltd.
Adresse du fabricant :	5 Shlomo Kaplan Street, Tel Aviv 67897, Israël
Modèles réglementés :	T92
Modèles de marketing :	SG2580
Options de produit :	Par câble uniquement
Date de demande initiale :	Avril 2025, Tel Aviv, Israël

Déclare, sous sa seule responsabilité, que les produits sont conformes aux spécifications suivantes :

Certification	Type
EN 55032:2015/A11:2020, classe B EN 55035:2017/A11:2020 EN IEC 61000-3-2:2019/A1:2021 EN 61000-3-3:2013/A2:2021 AS/NZS CISPR 32:2015 AMD 1:2020 BS EN 55032:2015+A11:2020, Classe B BS EN 55035:2017+A11:2020 BS EN IEC 61000-3-2:2019+A1:2021 BS EN 61000-3-3:2013+A2:2021 IEC 61000-4-2 Ed. 2.0:2008 IEC 61000-4-3 Ed. 4.0:2020 IEC 61000-4-4 Ed. 3.0:2012 IEC 61000-4-5 Ed. 3.1:2017 IEC 61000-4-6 Ed. 5.0:2023 IEC 61000-4-8 Ed. 2.0:2009 IEC 61000-4-11 Ed. 3.0:2020 Pièce 47 CFR FCC Sous-composant 15 B ICES-003 émission 7 : octobre 2020 ANSI C63.4 : 2014 VCCI-CISPR 32 : 2017	EMI (Interférence électromagnétique) et EMC (Compatibilité électromagnétique)
CE LVD EN62368-1 CB IEC /EN62368-1 2e et 3e édition. AS/NZS 62368.1:2022 CSA C22.2 n° 62368-1:2019 GB 4943.1-2022 EN IEC 62368-1:2020+A11:2020, BS EN IEC 62368-1:2020+A11:2020 J62368-1 (2023) Norme nationale SASO-IEC 62368-1:2020 UL 62368-1:2019 KC 62368-1 (2021-08) UL62368-1	Sécurité électrique

Laboratoires d'essais

Prodigy Technology Consultant Co.	No. 12, Gong 7th Rd., Linkou District, New Taipei City 24450, Taïwan.
DEKRA Testing and Certification Co, Ltd.	No. 85, Wenlin St., Linkou Dist., New Taipei City, 244017, Taïwan.

Directive de l'Union européenne (UE) sur la compatibilité électromagnétique et la sécurité

Ce produit est certifié conforme aux exigences de la directive du Conseil concernant le rapprochement des législations des États membres relatives aux directives sur la compatibilité électromagnétique (2004/108/CE et 2014/30/UE). Ce produit est conforme aux directives basse tension 2006/95/CE et 2014/35/UE. Ce produit satisfait aux exigences des directives 2006/95/CE et 2014/35/UE du Conseil relatives aux équipements électriques conçus pour être utilisés dans une certaine plage de tensions, selon les modifications de la directive 93/68/CEE.

Avis de la Commission fédérale des communications (FCC) (États-Unis)

Cet équipement a été testé et déclaré conforme aux limites d'un appareil numérique de classe A, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles lorsque l'équipement est utilisé dans un environnement commercial. Cet équipement génère, utilise et peut émettre des fréquences radio et, s'il n'est pas installé et utilisé conformément au manuel d'instructions, peut causer des interférences nuisibles aux communications radio. L'utilisation de cet équipement dans une zone résidentielle est susceptible de provoquer des interférences nuisibles, auquel cas l'utilisateur devra corriger les interférences à ses propres frais.

Déclaration à la FCC sur l'exposition aux rayonnements

Cet équipement respecte les limites de la FCC en matière d'exposition aux rayonnements radio, pour un environnement non contrôlé. Cet équipement doit être installé et utilisé en réservant au moins 20 cm entre l'élément rayonnant et l'utilisateur. Ce dispositif est conforme à la section 15 des réglementations de la FCC. Son fonctionnement est soumis aux deux conditions suivantes :

Informations sur la conformité

1. Cet appareil ne doit pas provoquer d'interférences nuisibles, et
2. Cet appareil doit accepter toute interférence reçue, y compris les interférences susceptibles de provoquer un fonctionnement indésirable.

Cet émetteur ne doit pas être installé ou utilisé en conjonction avec d'autres antennes ou émetteurs.

Déclaration du département canadien de la conformité

Cet appareil est conforme aux règles ICES-003 d'Industrie Canada.

Déclaration de conformité de la classe B au Japon

Il s'agit d'un produit de classe B selon la norme du Voluntary Control Council for Interference (VCCI).

Si cet appareil est utilisé dans un environnement domestique, des interférences radio peuvent se produire, auquel cas l'utilisateur peut être tenu de prendre des mesures correctives.

この装置は、クラスB 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

Fiabilité physique et environnementale	Description
Conditions de fonctionnement	Vibrations et chocs sur la base de la norme EN 300 019-2-3. Température : 0 °C ~ 40 °C
Conditions d'entreposage	Température : (-40) °C ~ 60 °C. Humidité : 95 %, sans condensation. Vibrations et chocs sur la base de la norme EN 300 019-2-1.
Conditions de transport	Température : (-40) °C ~ 85 °C. Humidité : 95 %, sans condensation. Vibrations et chocs sur la base de la norme EN 300 019-2-2.

Support

For technical assistance, contact Check Point 24 hours a day, seven days a week at:

- +1 972-444-6600 (Americas)
- +972 3-611-5100 (International)

When you contact support, you must provide your MAC address.

For more technical information, go to: [Check Point Support Center](#).

To learn more about the Check Point Internet Security Product Suite and other security solutions, go to: <https://www.checkpoint.com>