



QUANTUM

19 January 2025

# QUANTUM SMART-1 600- S APPLIANCES

Getting Started Guide



# Check Point Copyright Notice

© 2021 - 2025 Check Point Software Technologies Ltd.

All rights reserved. This product and related documentation are protected by copyright and distributed under licensing restricting their use, copying, distribution, and decompilation. No part of this product or related documentation may be reproduced in any form or by any means without prior written authorization of Check Point. While every precaution has been taken in the preparation of this book, Check Point assumes no responsibility for errors or omissions. This publication and features described herein are subject to change without notice.

## RESTRICTED RIGHTS LEGEND:

Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c) (1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and FAR 52.227-19.

## TRADEMARKS:

Refer to the [Copyright page](#) for a list of our trademarks.

Refer to the [Third Party copyright notices](#) for a list of relevant copyrights and third-party licenses.

# Table of Contents

---

|                                                                                          |           |
|------------------------------------------------------------------------------------------|-----------|
| <b>Safety, Environmental, and Electronic Emissions Notices</b>                           | <b>6</b>  |
| <b>Compliance Information</b>                                                            | <b>10</b> |
| Declaration of Conformity                                                                | 10        |
| <b>Remarques relatives à la sécurité, l'environnement et les émissions électroniques</b> | <b>14</b> |
| <b>Hinweise zu Sicherheit, Umwelt und elektronischen Emissionen</b>                      | <b>18</b> |
| <b>Introduction</b>                                                                      | <b>22</b> |
| Welcome                                                                                  | 22        |
| Quantum Smart-1 600-S Overview                                                           | 22        |
| Shipping Carton Contents                                                                 | 23        |
| Terminology                                                                              | 23        |
| <b>Mounting the Appliances in a Rack</b>                                                 | <b>25</b> |
| Appliance Physical Specifications                                                        | 25        |
| Appliance Air Vents                                                                      | 25        |
| <b>Configuring the Appliances</b>                                                        | <b>26</b> |
| Starting the Appliance                                                                   | 26        |
| Available Software Images                                                                | 26        |
| Initial Configuration                                                                    | 26        |
| Advanced Configuration                                                                   | 26        |
| Connecting to the Smart-1 600-S Appliances CLI                                           | 26        |
| <b>Smart-1 600-S Appliances Hardware</b>                                                 | <b>27</b> |
| Front Panel                                                                              | 27        |
| Front Panel Ports                                                                        | 28        |
| Front Panel System LEDs                                                                  | 29        |
| Rear Panel                                                                               | 29        |
| Using the Power Cable Restraint Strip                                                    | 31        |
| Dual Redundant BIOS                                                                      | 32        |
| Replacing and Upgrading Components                                                       | 33        |
| <b>Restoring Factory Defaults</b>                                                        | <b>34</b> |
| Restoring from the Gaia Portal                                                           | 34        |
| Restoring from the Boot Menu                                                             | 34        |
| Restoring from Gaia Clish                                                                | 35        |
| <b>Registration and Support</b>                                                          | <b>36</b> |
| Registration                                                                             | 36        |

---

---

|                           |    |
|---------------------------|----|
| Support .....             | 36 |
| Where To From Here? ..... | 36 |

# Important Information



## Latest Software

We recommend that you install the most recent software release to stay up-to-date with the latest functional improvements, stability fixes, security enhancements and protection against new and evolving attacks.



## Certifications

For third party independent certification of Check Point products, see the [Check Point Certifications page](#).



## Check Point Quantum Smart-1 600-S Appliances

For more about this release, see the [home page](#).



## Latest Version of this Document in English

Open the latest version of this [document in a Web browser](#).

Download the latest version of this [document in PDF format](#).



## Feedback

Check Point is engaged in a continuous effort to improve its documentation.

[Please help us by sending your comments.](#)

## Revision History

| Date             | Description                                                                  |
|------------------|------------------------------------------------------------------------------|
| 17 February 2022 | Rebranding - New Check Point logo                                            |
| 21 April 2021    | Updated information in <i>"Smart-1 600-S Appliances Hardware"</i> on page 27 |
| 14 April 2021    | First release of this document                                               |

# Safety, Environmental, and Electronic Emissions Notices

Read the following warnings before setting up or using the appliance.



**Warning** - Do not block air vents. A minimum 1/2-inch clearance is required.

Before you install or remove a chassis, or work near power supplies, turn off the power and unplug the power cord.

To prevent damage to any system board, it is important to handle it with care. The following measures are generally sufficient to protect your equipment from static electricity discharge:

- When handling the board, to use a grounded wrist strap designed for static discharge elimination.
- Touch a grounded metal object before removing the board from the antistatic bag.
- Handle the board by its edges only. Do not touch its components, peripheral chips, memory modules or gold contacts.
- When handling processor chips or memory modules, avoid touching their pins or gold edge fingers.
- Restore the communications appliance system board and peripherals back into the antistatic bag when they are not in use or not installed in the chassis. Some circuitry on the system board can continue operating even though the power is switched off.
- Under no circumstances should the lithium battery cell used to power the real-time clock be allowed to short. The battery cell may heat up under these conditions and present a burn hazard.



**Warning** - DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

- Disconnect the system board power supply from its power source before you connect or disconnect cables or install or remove any system board components. Failure to do this can result in personnel injury or equipment damage.
- Avoid short-circuiting the lithium battery; this can cause it to superheat and cause burns if touched.
- Do not operate the processor without a thermal solution. Damage to the processor can occur in seconds.
- Class 1 laser product warning - A totally enclosed laser system containing a class 1 laser.

This device is not intended for use in the direct field of view at visual display workplaces. To avoid incommoding reflexions at visual display workplaces this device must not be placed in the direct field of view.

## Rack Mount Instructions

The following or similar rack-mount instructions are included with the installation instructions:

1. **Elevated Operating Ambient** - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature specified by the manufacturer.
2. **Reduced Air Flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
3. **Mechanical Loading** - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
4. **Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
5. **Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

**For California:**

**Perchlorate Material** - special handling may apply. See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

The foregoing notice is provided in accordance with California Code of Regulations Title 22, Division 4.5, Chapter 33. Best Management Practices for Perchlorate Materials. This product, part, or both may include a lithium manganese dioxide battery which contains a perchlorate substance.

**Proposition 65 Chemical**

Chemicals identified by the State of California, pursuant to the requirements of the California Safe Drinking Water and Toxic Enforcement Act of 1986, California Health & Safety Code s. 25249.5, et seq. ("Proposition 65"), that is "known to the State to cause cancer or reproductive toxicity" (see <http://www.calepa.ca.gov>)

**WARNING:**

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling.

**Caution**

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

**Information to user:**

The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

**Canadian Department Compliance Statement:**

This Class A digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

**Japan Compliance Statement:****Class A**

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

**European Union (EU) Electromagnetic and Safety Compatibility Directives - Smart-1 600-S Appliances**

This product is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directives 2004/108/EC and 2014/30/EU.

This product is in conformity with Low Voltage Directives 2006/95/EC and 2014/35/EU.

This product complies with the requirements in the Council Directives 2006/95/EC and 2014/35/EU relating to electrical equipment designed for use within certain voltage limits and the Amendment Directive 93/68/EEC.



### Product Disposal

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office or your household waste disposal service.

# Compliance Information

This appendix contains declaration of conformity, compliance, and related regulatory information.

## Declaration of Conformity

**Manufacturer's Name:** Check Point Software Technologies Ltd.

**Manufacturer's Address:** 5 Shlomo Kaplan Street  
Tel Aviv 6789159, Israel

Declare that under our sole responsibility the product

**Model Number:** QS-2

**Product Options:** Smart-1 600-S

**Date First Applied:** January 2020

Conforms to the following Product Specifications:

| Category | Technical Specification                                                   | Description                                                          |
|----------|---------------------------------------------------------------------------|----------------------------------------------------------------------|
| EMC      | FCC 47 CFR Part 15 Subpart B,<br>ICES-003 Issue 6-2016<br>ANSI C63.4-2014 | Information Technology Equipment - Radio Disturbance Characteristics |
|          | VCCI-CISPR 32: 2016                                                       | Information Technology Equipment - Radio Disturbance Characteristics |
|          | AS/NZS CISPR 32: 2013<br>CISPR 32: 2012 (Ed 1.0)                          | Information Technology Equipment - Radio Disturbance Characteristics |
|          | EN 55032: 2012/AC: 2013 Class A<br>CISPR 32:2012                          | Information Technology Equipment - Radio Disturbance Characteristics |
|          | EN 55024                                                                  |                                                                      |
|          | EN 61000-3-2: 2014                                                        | Information Technology Equipment - Harmonics Characteristics         |
|          | EN 61000-3-3: 2013                                                        | Information Technology Equipment - Harmonics Characteristics         |
|          | EN 55024: 2010+A1:2015                                                    | Immunity characteristics - Limits and methods of measurement         |
|          | IEC 61000-4-2: 2008                                                       | Information Technology Equipment - Flicker Characteristics           |
|          | IEC 61000-4-3: 2006                                                       | Information Technology Equipment - Radiated RF Immunity              |

| Category | Technical Specification                                                              | Description                                                                      |
|----------|--------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| EMC      | IEC 61000-4-4                                                                        | Information Technology Equipment - Fast Transient Immunity                       |
|          | IEC 61000-4-5                                                                        | Information Technology Equipment - Surge Immunity                                |
|          | IEC 61000-4-6                                                                        | Information Technology Equipment - Conducted RF Immunity                         |
|          | IEC 61000-4-8                                                                        | Information Technology Equipment - Power frequency magnetic field immunity test  |
|          | IEC 61000-4-11                                                                       | Information Technology Equipment - Voltage Dips and Short Interruptions Immunity |
|          | IEC 61000-4-12                                                                       | Information Technology Equipment - Ring wave immunity test                       |
| RoHS     | 2011/65/EU                                                                           | RoHS Directive                                                                   |
| Safety   | UL GS / IEC 60950-1: 2005 (Second Edition)+Am 1:2009+Am 2: 2013<br>EN 62368-1 : 2014 | Information technology equipment.<br>Safety General requirements, CE LVD         |
|          | UL/ULc 60950-1<br>UL 62368-1                                                         | Information technology equipment<br>Safety General requirements                  |

Date and Place of issue: January, 2020, Tel Aviv, Israel - QS-2

### European Union (EU) Electromagnetic and Safety Compatibility Directive

This product is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility Directives 2004/108/EC and 2014/30/EU.

This product is in conformity with Low Voltage Directives 2006/95/EC and 2014/35/EU.

This product complies with the requirements in the Council Directives 2006/95/EC and 2014/35/EU relating to electrical equipment designed for use within certain voltage limits and the Amendment Directive 93/68/EEC.

### Federal Communications Commission (FCC) Notice (US)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Canadian Department Compliance Statement

This device complies with Industry Canada ICES-003 rules. Cet appareil est conforme aux normes NMB003 d'Industrie Canada.

### Japan Class A Compliance Statement:

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

### GS Safety Notice

|                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Protective earthing is used as a safeguard | Ensure connection of the power cord to a socket-outlet with earthing connection, or equivalent                                                                                                                                                                                                                                                                                                                                                                                        |
| Restrict Access Area Instruction           | <p>It is recommended that equipment be installed only in a server room or computer room where access is:</p> <ul style="list-style-type: none"> <li>■ Restricted to qualified service personnel or users familiar with restrictions applied to the location, reasons therefor, and any precautions required.</li> <li>■ Only accessible by the use of a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location.</li> </ul> |
| Die Erdung diehnt als Sicherheitsmassnahme | Stellen Sie sicher, dass das Netzkabel an eine Steckdose mit Erdungsanschluss oder einem gleichwertigen Anschluss angeschlossen ist                                                                                                                                                                                                                                                                                                                                                   |

|                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Beschränken Sie die Zutrittsrechte! | <p>Es wird empfohlen, Geräte nur in einem Server- oder Computerraum zu installieren, in dem Folgendes möglich ist:</p> <ul style="list-style-type: none"> <li>■ Nur für qualifiziertes Servicepersonal oder Benutzer, die mit den Einschränkungen des Standorts, den Gründen dafür und den erforderlichen Vorsichtsmaßnahmen vertraut sind.</li> <li>■ Nur mit einem Werkzeug, einem Schloss und einem Schlüssel oder einem anderen Sicherheitsmittel zugänglich und wird von der für den Standort zuständigen Behörde kontrolliert.</li> </ul> |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## CCC Note



标识的涵义: 设备仅适用于海拔2000M以下地区安全使用

## BSMI Note

警告使用者：

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

| 單元 Unit                                                                                                                                                                                                                                                                     | 限用物質及其化學符號<br>Restricted substances and its chemical symbols |                |                |                                             |                                     |                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|----------------|----------------|---------------------------------------------|-------------------------------------|---------------------------------------------|
|                                                                                                                                                                                                                                                                             | 鉛 Lead (Pb)                                                  | 汞 Mercury (Hg) | 鎘 Cadmium (Cd) | 六價鉻 Hexavalent chromium (Cr <sup>6+</sup> ) | 多溴聯苯 Polybrominated biphenyls (PBB) | 多溴二苯醚 Polybrominated diphenyl ethers (PBDE) |
| 印刷電路板 (PCB),                                                                                                                                                                                                                                                                | ○                                                            | ○              | ○              | ○                                           | ○                                   | ○                                           |
| 電源模組, (power module),                                                                                                                                                                                                                                                       | 超出<br>0.1 wt %                                               | ○              | ○              | ○                                           | ○                                   | ○                                           |
| 金屬部件, (Metal Parts),                                                                                                                                                                                                                                                        | ○                                                            | ○              | ○              | ○                                           | ○                                   | ○                                           |
| 晶片電阻, (Chips),                                                                                                                                                                                                                                                              | 超出<br>0.1 wt %                                               | ○              | ○              | ○                                           | ○                                   | ○                                           |
| 備考1. “超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。 <sup>4)</sup><br>Note 1: “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition. <sup>4)</sup> |                                                              |                |                |                                             |                                     |                                             |
| 備考2. “○”係指該項限用物質之百分比含量未超出百分比含量基準值。 <sup>4)</sup><br>Note 2: “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence. <sup>4)</sup>                                                              |                                                              |                |                |                                             |                                     |                                             |
| 備考3. “—”係指該項限用物質為排除項目。 <sup>4)</sup><br>Note 3: The “—” indicates that the restricted substance corresponds to the exemption. <sup>4)</sup>                                                                                                                                 |                                                              |                |                |                                             |                                     |                                             |

# Remarques relatives à la sécurité, l'environnement et les émissions électroniques

Avant de mettre en place ou d'utiliser l'appareil, veuillez lire les avertissements suivants.



**Avertissement:** ne pas obturer les aérations. Il faut laisser au moins 1,27 cm d'espace libre.

Avant d'installer ou retirer un châssis ou de travailler à proximité d'alimentations, mettez-le hors tension et débranchez le cordon d'alimentation.

Pour éviter d'endommager les cartes système, il est important de les manipuler avec soin. Les mesures suivantes sont généralement suffisantes pour protéger votre équipement contre les décharges d'électricité statique :

- Avant de manipuler la carte, portez aux poignet un bracelet antistatique relié à la terre.
- Touchez un objet métallique relié à la terre avant d'extraire la carte de son sachet antistatique.
- Ne tenez la carte que par ses bords. Ne touchez aucun composant, puce périphérique, module mémoire ou contact plaqué or.
- Lorsque vous manipulez des processeurs ou des modules mémoire, évitez de toucher leurs broches ou les pistes de contact dorées.
- Remettez dans leur sachet antistatique la carte système et les périphériques de l'appareil de communications lorsqu'ils ne sont pas utilisés ou installés dans le châssis. Certains circuits sur la carte système peuvent rester fonctionnels même si l'appareil est éteint.
- Il ne faut jamais court-circuiter la pile au lithium qui alimente l'horloge temps-réel. Elle risque de s'échauffer et de causer des brûlures.



**Avertissement:** DANGER D'EXPLOSION SI LA PILE EST MAL REMPLACÉE. NE REMPLACER QU'AVEC UN TYPE IDENTIQUE OU ÉQUIVALENT, RECOMMANDÉ PAR LE CONSTRUCTEUR. LES PILES DOIVENT ÊTRE MISES AU REBUT CONFORMÉMENT AUX INSTRUCTIONS DE LEUR FABRICANT.

- Débrancher l'alimentation de la carte système de sa source électrique avant de connecter ou déconnecter des câbles ou d'installer ou retirer des composants. À défaut, les risques sont d'endommager l'équipement et de causer des blessures corporelles.
- Ne pas court-circuiter la pile au lithium : elle risque de surchauffer et de causer des brûlures en cas de contact.
- Ne pas faire fonctionner le processeur sans refroidissement. Le processeur peut être endommagé en quelques secondes.
- Produit laser de classe 1 : un système laser totalement clos et contenant un laser de classe 1.

Cet appareil n'est pas prévu pour être utilisé dans le champ de vision direct des personnes occupant un bureau. Pour éviter toute gêne occasionnée par un éventuel reflet, cet appareil ne doit pas être placé dans le champ de vision direct des personnes occupant un bureau.

## Instructions de montage en rack

Les instructions d'installation sont livrées avec les instructions de montage en rack ci-après (ou similaires) :

1. Fonctionnement à température plus élevée : si l'appareil est installé dans une armoire fermée ou un rack à plusieurs unités, la température du rack en fonctionnement peut être supérieure à la température ambiante de la pièce. Avant d'installer l'équipement, il faut donc s'assurer qu'il sera dans un environnement compatible avec la température ambiante maximale indiquée par le constructeur.
2. Circulation d'air réduite : l'installation dans un rack doit s'assurer de ne pas limiter la circulation de l'air nécessaire au bon fonctionnement de l'équipement.
3. Charge mécanique : lors du montage de l'équipement dans le rack, il faut faire attention à ne pas déséquilibrer l'ensemble. Un rack se remplit en commençant par le bas.
4. Surcharge : pour la connexion de l'équipement au circuit électrique, il faut vérifier les risques de surcharge et les éventuelles conséquences sur la protection contre les surcourants et sur le câblage électrique. Dans ce contexte, il faut tenir compte des informations mentionnées par la plaque technique de l'instrument.
5. Mise à la terre : les équipements montés en rack doivent être en permanence reliés à un terre fiable. Il faut faire particulièrement attention aux branchements qui ne vont pas directement à la source électrique (par exemple des multiprises).

### Pour la Californie :

**Matériau perchloraté** : manipulation spéciale potentiellement requise. Voir <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

L'avis suivant est fourni conformément au California Code of Regulations, titre 22, division 4.5, chapitre 33. Meilleures pratiques de manipulation des matériaux perchloratés. Ce produit, cette pièce ou les deux peuvent contenir une pile au dioxyde de lithium manganèse, qui contient une substance perchloratée.

### Produits chimiques « Proposition 65 »

Les produits chimiques identifiés par l'état de Californie, conformément aux exigences du California Safe Drinking Water and Toxic Enforcement Act of 1986 du California Health & Safety Code s. 25249.5, et seq. (« Proposition 65 »), qui sont « connus par l'état pour être cancérigène ou être toxiques pour la reproduction » (voir <http://www.calepa.ca.gov>)

## AVERTISSEMENT :

La manipulation de ce cordon vous expose au contact du plomb, un élément reconnu par l'état de Californie pour être cancérigène, provoquer des malformations à la naissance et autres dommages relatifs à la reproduction. Se laver les mains après toute manipulation.

### Attention

Toute modification non approuvée expressément par la garantie du présent appareil pourrait annuler le droit de l'utilisateur à faire fonctionner l'équipement.

Ce dispositif est conforme à la section 15 des réglementations de la FCC. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférence préjudiciable et (2) Cet appareil doit tolérer toute interférence reçue, y compris celles qui pourraient causer un fonctionnement indésirable.

### Attention !

Le fabricant n'est pas responsable des éventuelles interférences radio ou TV dues à des modifications non autorisées du présent équipement. Ces modifications pourraient annuler le droit de l'utilisateur à faire fonctionner l'équipement.

Ce dispositif est conforme à la section 15 des réglementations de la FCC. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférence préjudiciable et (2) Cet appareil doit tolérer toute interférence reçue, y compris celles qui pourraient causer un fonctionnement indésirable.

### Attention?!

Le fabricant n'est pas responsable des éventuelles interférences radio ou TV dues à des modifications non autorisées du présent équipement. Ces modifications pourraient annuler le droit de l'utilisateur à faire fonctionner l'équipement.

## Information à l'intention de l'utilisateur :

Le manuel utilisateur ou le manuel d'instruction d'un dispositif rayonnant (intentionnel ou non) doit avertir que toute modification non approuvée expressément par la partie responsable de la conformité peut annuler le droit de faire fonctionner l'équipement. Si le manuel n'est pas fourni sous forme imprimée (par exemple sur le disque d'un ordinateur ou via Internet), les informations requises par cette section doivent être incluses dans ces versions du manuel, sous réserve que l'utilisateur soit raisonnablement capable d'y accéder.

## Déclaration de conformité du département canadien :

This Class A digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

## Déclaration de conformité pour le Japon :

### Classe A

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

**Directives de l'Union européenne (UE) relatives à la compatibilité électromagnétique et à la sécurité - Appareils 6200, 6400, 6500, 6600, 6700, 6800 6900 et 7000**

Ce produit est certifié conforme aux exigences de la directive du Conseil concernant le rapprochement des législations des États membres relatives aux directives sur la compatibilité électromagnétique (2004/108/CE et 2014/30/UE).

Ce produit est conforme aux directives basse tension 2006/95/CE et 2014/35/UE.

Ce produit satisfait aux exigences des directives 2006/95/CE et 2014/35/UE du Conseil relatives aux équipements électriques conçus pour être utilisés dans une certaine plage de tensions, selon les modifications de la directive 93/68/CEE.



**Mise au rebut du produit**

Ce symbole apposé sur le produit ou son emballage signifie que le produit ne doit pas être mis au rebut avec les autres déchets ménagers. Il est de votre responsabilité de le porter à un centre de collecte désigné pour le recyclage des équipements électriques et électroniques. Le fait de séparer vos équipements lors de la mise au rebut, et de les recycler, contribue à préserver les ressources naturelles et s'assure qu'ils sont recyclés d'une façon qui protège la santé de l'homme et l'environnement. Pour obtenir plus d'informations sur les lieux où déposer vos équipements mis au rebut, veuillez contacter votre municipalité ou le service de gestion des déchets.

# Hinweise zu Sicherheit, Umwelt und elektronischen Emissionen

Lesen Sie die folgenden Warnhinweise durch, bevor Sie das Gerät einrichten oder verwenden.



**Warnhinweis** - Die Lüftungsschlitze müssen frei gehalten werden. Der Mindestabstand beträgt 0,5 Zoll (1,27 cm).

Schalten Sie das Gerät ab und ziehen Sie den Stecker, bevor Sie ein Gestell anbringen oder entfernen oder wenn Sie in der Nähe der Stromzufuhr arbeiten.

Es ist wichtig, dabei sorgfältig vorzugehen, um Schäden an den Systemplatinen zu vermeiden. Die folgenden Maßnahmen reichen in der Regel aus, um Ihre Anlage vor elektrostatischer Entladung zu schützen:

- Tragen Sie eine geeignete Erdungsmanschette gegen die statische Entladung, wenn Sie die Platine berühren.
- Berühren Sie einen geerdeten metallischen Gegenstand, bevor Sie die Platine aus der antistatischen Schutzhülle nehmen.
- Berühren Sie die Platine nur an den Rändern. Berühren Sie nicht die Komponenten, zugehörigen Chips, Speichermodule oder goldenen Kontakte.
- Wenn Sie mit Prozessor-Chips oder Speichermodulen arbeiten, berühren Sie nicht die Pins oder die goldenen Einsteckstellen am Rand der Platine.
- Wenn die Systemplatine des Kommunikationsgerätes nicht verwendet oder angebracht wird, verstauen Sie sie wieder in der antistatischen Schutzhülle. Einige der Schaltkreise auf der Systemplatine werden unter Umständen auch dann betrieben, wenn die Stromzufuhr unterbrochen wurde.
- An der Lithiumbatterie, die den Absolutzeitgeber betreibt, sollte unter keinen Umständen ein Kurzschluss möglich sein. In diesem Fall könnte sich die Batterie erhitzen und eine Verbrennungsgefahr darstellen.



**Warnhinweis** - EXPLOSIONSGEFAHR BEI NICHT ORDNUNGSGEMÄSS EINGESETZTER BATTERIE. NUR GEMÄSS HERSTELLEREMPFEHLUNGEN DURCH GLEICHEN ODER ÄQUIVALENTEN TYP ERSETZEN. GEBRAUCHTE BATTERIEN GEMÄSS HERSTELLERANWEISUNGEN ENTSORGEN.

- Trennen Sie die Stromversorgung der Systemplatine von der entsprechenden Stromquelle, bevor Sie Kabel ein- bzw. ausstecken oder Komponenten der Systemplatine entfernen. Wenn Sie dies nicht befolgen, können Personen verletzt und die Anlage beschädigt werden.
- Schließen Sie die Lithiumbatterie nicht kurz; dies kann zur Überhitzung der Batterie und bei Berühren zu Verbrennungen führen.
- Betreiben Sie den Prozessor nur mit einer geeigneten Lösung für die Wärmekontrolle. Der Prozessor kann innerhalb von wenigen Sekunden beschädigt werden.
- Produktwarnung Laserklasse 1 - ein vollständig geschlossenes Lasersystem mit einem Laser der Klasse 1.

Das Gerät ist nicht für den Einsatz im direkten Blickfeld von Bildschirmarbeitsplätzen geeignet. Das Gerät darf nicht im direkten Blickfeld von Bildschirmarbeitsplätzen angebracht werden, um ein unangenehmes Reflektieren zu vermeiden.

## Anleitung zur Rackmontage

Die nachfolgende Anleitung zur Rackmontage ist Teil der Installationsanleitung:

1. Erhöhte Betriebsumgebung - Wenn das Gerät in einer geschlossenen Rackbaugruppe oder in einer Rackbaugruppe mit mehreren Einheiten installiert wird, ist die Umgebungsbetriebstemperatur des Racks unter Umständen höher als die Raumtemperatur. Deshalb sollte darauf geachtet werden, die Anlage in einer Umgebung zu installieren, die mit der vom Hersteller angegebenen Maximaltemperatur kompatibel ist.
2. Verringerter Luftstrom - Die Anlage sollte so in das Rack installiert werden, dass der für einen sicheren Betrieb der Anlage benötigte Luftstrom nicht beeinträchtigt wird.
3. Mechanische Ladung - Die Anlage sollte so im Rack installiert werden, dass keine Gefahr durch ungleichmäßig verteilte mechanische Ladung besteht.
4. Systemüberlastung - Es muss darauf geachtet werden, wie die Anlage an den Versorgungskreis angeschlossen ist, und wie sich eine Überlastung des Systems auf den Überstromschutz und die Versorgungskabel auswirken könnte. Bei diesem Thema sollte auf ein angemessenes Typenschild der Anlage geachtet werden.
5. Zuverlässige Erdung - Die rackmontierte Anlage muss sicher geerdet werden. Besondere Vorsicht ist bei Versorgungsanschlüssen geboten, die nicht direkt mit dem Netzstromkreis verbunden sind (z. B. beim Verwenden von Mehrfachsteckdosen).

## Für Kalifornien:

**Perchloratmaterial** - Evtl. spezielle Handhabung erforderlich. Siehe <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

Der vorhergehende Hinweis gilt in Übereinstimmung mit dem „California Code of Regulations“ Titel 22, Abschnitt 4.5, Kapitel 33. Best Management Practices für Perchloratmaterialien. Dieses Produkt und/oder Teile davon umfassen eine Lithium-Mangandioxid-Batterie, die eine perchlorate Substanz enthält.

## Proposition 65, Chemikalien

Chemikalien, die vom US-Bundesstaat Kalifornien gemäß den Anforderungen des „California Safe Drinking Water and Toxic Enforcement Act“ von 1986 (California Health & Safety Code s. 25249.5 ff., „Proposition 65“) als mögliche Ursache für Krebs oder eine fortpflanzungsgefährdende Toxizität eingestuft werden (siehe <http://www.calepa.ca.gov>)

## WARNUNG:

Im Kabel dieses Produktes befindet sich Blei; diese Chemikalie wird vom US-Bundesstaat Kalifornien als mögliche Ursache für Krebs, Geburtsfehler oder Einschränkungen der Fortpflanzungsfähigkeit eingestuft. Waschen Sie sich anschließend die Hände.

## Vorsicht

Sämtliche Änderungen oder Modifikationen, die nicht ausdrücklich in der Garantieerklärung dieses Geräts gestattet werden, führen möglicherweise zum Erlöschen der Betriebserlaubnis des Benutzers.

Diese Anlage erfüllt Teil 15 der FCC-Regeln. Der Betrieb unterliegt den folgenden zwei Beschränkungen: (1) Das Gerät verursacht keine schädlichen Interferenzen und (2) Dieses Gerät toleriert alle empfangenen Störungen, einschließlich der Störungen, die einen unerwünschten Betrieb zur Folge haben.

## Vorsicht!

Der Hersteller ist für keinerlei Störungen des Radio- oder Fernsehempfangs verantwortlich, die durch nicht genehmigte Änderungen dieser Anlage hervorgerufen werden. Derartige Änderungen können zu einem Entzug der Betriebserlaubnis für diese Anlage führen.

#### Benutzerinformationen:

Die Betriebs- oder Gebrauchsanleitung eines beabsichtigten oder unbeabsichtigten Radiators dienen dazu, den Benutzer vor Änderungen oder Umrüstungen zu warnen, die nicht ausdrücklich von der zuständigen Stelle für Konformität genehmigt wurden, da diese zu einem Entzug der Betriebserlaubnis für diese Anlage führen können. Wenn das Handbuch nur in anderer als gedruckter Form zur Verfügung steht, zum Beispiel auf einer Computerfestplatte oder über das Internet, ist die gemäß diesem Abschnitt erforderliche Information im Handbuch möglicherweise in dieser alternativen Form enthalten, sofern vom Benutzer erwartet werden kann, dass er auf Informationen dieser Form Zugriff hat.

#### Konformitätserklärung des Kanadischen Ministeriums:

Dieses digitale Gerät der Klasse A erfüllt die kanadische Norm ICES-003. Dieses digitale Gerät der Klasse A erfüllt die kanadische Norm NMB-003.

#### Konformitätserklärung Japan:

##### Klasse A

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

#### Richtlinien der Europäischen Union (EU) bezüglich elektromagnetischer Verträglichkeit und Sicherheit - Geräte 6200, 6400, 6500, 6600, 6700, 6800, 6900 und 7000

Hiermit wird erklärt, dass dieses Produkt mit den Auflagen der Richtlinie des Europäischen Rates bezüglich zur Angleichung der Rechtsvorschriften der Mitgliedstaaten im Hinblick auf die Richtlinien über elektromagnetische Verträglichkeit (2004/108/EG) und 2014/30/EU konform ist.

Dieses Produkt ist mit den Niederspannungsrichtlinien 2006/95/EG 2014/35/EU konform.

Dieses Produkt ist mit den Richtlinien des Rates 2006/95/EG und 2014/35/EU konform betreffend elektrischer Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen und der Änderungsrichtlinie 93/68/EWG.



## Produktentsorgung

Dieses Symbol auf dem Produkt oder dessen Verpackung gibt an, dass das Produkt nicht zusammen mit Restmüll entsorgt werden darf. Es obliegt daher Ihrer Verantwortung, das Gerät an einer entsprechenden Stelle für die Entsorgung oder Wiederverwertung von Elektrogeräten aller Art abzugeben. Die separate Sammlung und das Recyceln Ihrer alten Elektrogeräte zum Zeitpunkt ihrer Entsorgung trägt zum Schutz der Umwelt bei und gewährleistet, dass die Geräte auf eine Art und Weise recycelt werden, die keine Gefährdung für die Gesundheit des Menschen und der Umwelt darstellt. Weitere Informationen darüber, wo Sie alte Elektrogeräte zum Recyceln abgeben können, erhalten Sie bei den örtlichen Behörden, den Wertstoffhöfen oder dort, wo Sie das Gerät erworben haben.

# Introduction

## Welcome

Thank you for choosing the Quantum Check Point Smart-1 600-S Appliance, part of the Check Point Infinity consolidated architecture. You are now minutes away from setting up the most advanced security platform designed to prevent the most sophisticated threats today and in the future. We hope that you will be satisfied with this system and our support services. Check Point products are the most up to date and secure solutions available today.

Check Point also delivers worldwide technical services including educational, professional and support services through a network of Authorized Training Centers, Certified Support Partners and Check Point technical support personnel to ensure that you get the most out of your security investment.

For additional information on the Internet Security Product Suite and other security solutions, refer to the Check Point [web site](#), or call Check Point at 1(800) 429-4391. For additional technical information about Check Point products, consult the [Check Point Support Center](#).

Welcome to the Check Point family. We look forward to meeting all of your current and future network, application and management security needs.

## Quantum Smart-1 600-S Overview

Smart-1 platforms welcome the 6th generation of Cyber Security. The Smart-1 600-S dedicated appliance is optimized for performance and scalability with both hardware and OS (operating system) hardened from the core.

Check Point Infinity architecture consolidates management of multiple security layers, providing superior policy efficiency and enables you to manage security through a single pane of glass. The single management centrally correlates all types of events across all network environments, cloud services and mobile infrastructures

The new Smart-1 appliances of the 6th generation are the gold standard platform for consolidated Security Management including policy, logs and events in a single box.

The new Smart-1 6th generation appliances deliver a performance boost of up to 40% compared to 5th generation appliances. This provides flexibility to double the number of managed gateways instantly.

Key features include:

- Up to 40% improvement in log collection with up to 63K logs/sec ingestion leading the industry with instantaneous search results
- Up to 80% faster report and views generation
- Optimized hardware and OS with the latest Gaia R81
- Double the system capacity in minutes by upgrading from Base to Plus package
- Faster system response and load times with increased memory (RAM) by 50% and up to 32GB
- Complete feature and tool set including full Threat visibility, best practices and compliance, SmartEvent and Multi-Domain management and automation
- Manage up to 10 Security Gateways

# Shipping Carton Contents

This section describes the contents of the shipping carton.

| Item                      | Description                                                                                                                                                                                                                                                                                               |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Appliance                 | Smart-1 600-S appliance                                                                                                                                                                                                                                                                                   |
| Rack Mounting Accessories | <ul style="list-style-type: none"> <li>■ Fixed rails and mount ears</li> <li>■ Rack mounting screws</li> <li>■ Ear bracket screws</li> </ul>                                                                                                                                                              |
| Cables and Adapters       | <ul style="list-style-type: none"> <li>■ 1 power cable for Smart-1 600-S appliances</li> <li>■ Power cable restraint</li> <li>■ 1 standard RJ-45 network cable</li> <li>■ 1 RJ-45 to DB9 serial console cable</li> <li>■ 1 USB Type-C serial console cable</li> <li>■ 1 RJ-45 loopback adapter</li> </ul> |
| Documentation             | <ul style="list-style-type: none"> <li>■ Quick Start Guide</li> <li>■ Rack Mounting Guide</li> <li>■ Image Management Guide (only applicable if the software image contains more than one release)</li> <li>■ User license agreement</li> <li>■ Battery Warning document</li> </ul>                       |



**Note** - DB9 connectors are also known as DE9 connectors.

## Terminology

The following terms are used in this guide:

- **Security Gateway:** The security engine that enforces the organization's security policy and acts as a security enforcement point.
- **Security Policy:** The Policy created by the system administrator that regulates the flow of incoming and outgoing communication.
- **Security Management Server:** The server used by the system administrator to manage the Security Policy. The organization's databases and Security Policies are stored on the Security Management Server and downloaded to the Security Gateway.
- **SmartConsole:** GUI applications that are used to manage various aspects of Security Policy enforcement.
- **SmartDashboard:** A Legacy SmartConsole GUI application that is used by the system administrator to create and manage specific settings for some Software Blades.

- **Locally Managed Deployment:** When all Check Point components responsible for both the management and enforcement of the Security Policy (the Security Management Server and the Security Gateway) are installed on the same machine.
- **Centrally Managed Deployment:** When the Security Gateway and the Security Management Server are installed on separate machines.

# Mounting the Appliances in a Rack

You can install your Smart-1 600-S appliance with the fixed rails or telescopic rails hardware (optional). See the [Installing the Quantum Smart-1 600-S Telescopic Rails](#) booklet for the procedure.

## Appliance Physical Specifications

These are the physical specifications of the Check Point appliance.

| Appliance     | Regulated Model | Width                  | Depth               | Height                    | Maximum Operating Temperature | Electrical Specifications           |
|---------------|-----------------|------------------------|---------------------|---------------------------|-------------------------------|-------------------------------------|
| Smart-1 600-S | QS-2            | 17.24 in<br>(43.80 cm) | 20 in<br>(50.80 cm) | 1.73 in<br>(4.40 cm) (1U) | 32° to 104°F<br>0° to 40°C    | 100-240V~<br>47-63Hz<br>2.5A - 1.5A |

## Appliance Air Vents

Make sure that the appliance air vents have sufficient airflow from front to rear when the appliance is mounted in a rack.




**Important** - If the appliance vents are blocked, the appliance can become too hot and it can be damaged.

**Warning** - This is a Class A product. It may cause electromagnetic interference. You may be required to take practical measures against the interference.

The appliance and rack rails have been tested in extreme conditions and do not block air flow to the appliance. These appliances are specifically designed to install with these rails.

The air flow in Smart-1 600-S appliances:



# Configuring the Appliances

## Starting the Appliance

Connect the appliance to a power source and turn on the appliance. When the appliance is ready, you can do the First Time Configuration Wizard to configure it.

### To start the appliance:

Connect the power cable to the power supply unit in the rear panel.

The appliance turns on.

## Available Software Images

The Smart-1 600-S appliances come with the R81 software image.

To follow the installation progress and see when the appliance is ready, connect to the appliance with a serial console cable.

For more about software images, see the [Smart-1 600-S/600-M/6000-L/6000-XL home page](#).

## Initial Configuration

Configure the appliance with the First Time Configuration Wizard. See the *Installation and Upgrade Guide* related to the software version.

Go to the *Installing a Security Management Server* section, and see the instructions to use the First Time Configuration Wizard.

## Advanced Configuration

You can configure advanced options on **Gaia** OS from the **Gaia** Portal or the **Gaia Clish**.

## Connecting to the Smart-1 600-S Appliances CLI

To connect to the command line interface, use one of these methods:

- An SSH connection to the management interface (if SSH is configured).
- A serial console cable and terminal emulation software, such as PuTTY (from Windows) or Minicom (from Unix/Linux).


Smart-1 600-S Appliances support these serial console connectivity options:

- USB Type-C - Using the included USB Type-C console cable .
- RJ45 - Using the included RJ-45 to DB9 serial console cable.

Connection parameters are: 9600bps, 8 bits, no parity, 1 stop bit (8N1), Flow Control - None.


# Smart-1 600-S Appliances Hardware

## Front Panel



| Item | Component                  | Description                                                                                                |
|------|----------------------------|------------------------------------------------------------------------------------------------------------|
| 1    | Expansion line card slot   | Expansion line card slot is not in use.                                                                    |
| 2    | On board LAN ports         | Eight 10/100/1000Base-T RJ-45 ports. These expansion slots are assigned eth1-eth8 in the OS.               |
| 3    | Appliance ports            | See <a href="#">"Front Panel Ports" on the next page</a> - Use these ports to connect to the appliance.    |
| 4    | System LEDs                | See <a href="#">"Front Panel System LEDs" on page 29</a> .                                                 |
| 5    | Reset                      | Insert a pin for 5 to 8 seconds to perform a hardware reset.                                               |
| 6    | Identification service tag | A slide out card that identifies the appliance and shows its serial number, MAC address, and model number. |
| 7    | Locator                    | Press the button to turn the Location beacon LED on and off in the appliance.                              |


## Front Panel Ports



| Item | Component            | Description                                                                                                                                  |
|------|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Synchronization port | Synchronize with cluster members.                                                                                                            |
| 2    | RJ45 console port    | For a serial connection to the appliance. See <a href="#">"Connecting to the Smart-1 600-S Appliances CLI" on page 26</a> .                  |
| 3    | Port activity LED    | <ul style="list-style-type: none"> <li>Off - No activity</li> <li>Slow Blink (Green) - Activity</li> </ul>                                   |
| 4    | Link speed LED       | <ul style="list-style-type: none"> <li>Off - No Link or 10M link</li> <li>On (Green) - 100M link</li> <li>On (Amber) - 1000M link</li> </ul> |
| 5    | Management port      | For an Ethernet connection to a remote management computer.                                                                                  |
| 6    | USB ports            | 2 USB 3.0 ports.                                                                                                                             |
| 7    | Console port         | A USB Type-C port for a serial connection to the appliance. See <a href="#">"Connecting to the Smart-1 600-S Appliances CLI" on page 26</a>  |


## Front Panel System LEDs

System power, storage device activity, power supply status, alert, and location.



| Item | Icon | Component               | Description                                                                                                                                                                                                                                                                                                                                                                           |
|------|------|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | ⓘ    | System power            | <ul style="list-style-type: none"> <li>Off - System power off</li> <li>On (Green) - System power on</li> </ul>                                                                                                                                                                                                                                                                        |
| 2    | 🗄️   | Storage device activity | <ul style="list-style-type: none"> <li>Off - No storage device activity</li> <li>On (Amber) - Read/write activity</li> </ul>                                                                                                                                                                                                                                                          |
| 3    | ⓘ    | Alert                   | <ul style="list-style-type: none"> <li>Off - No faults detected</li> <li>Blinking red - System fault detected</li> </ul>                                                                                                                                                                                                                                                              |
| 4    | 🏠    | Location beacon         | <ul style="list-style-type: none"> <li>Off - Location beacon is turned off</li> <li>Solid blue - Location beacon is turned on through the <b>Gaia Portal</b> or <b>Gaia Clish</b> or through the <b>Locator</b> button on the front panel</li> </ul> <p>Note - You can turn off the Location beacon LED from the <b>Locator</b> button, <b>Gaia Portal</b>, or <b>Gaia Clish</b>.</p> |


## Rear Panel



| Item | Component                           | Description                                                                                                                                                                                                                                                                                                                                                                        |
|------|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | LED indicator for power supply unit | <p>Off - Power supply is not connected to an electric outlet</p> <ul style="list-style-type: none"> <li>■ On (Amber) - Power off</li> <li>■ On (Green) - Power on</li> <li>■ On (Red) - Failure</li> </ul>                                                                                                                                                                         |
| 2    | Power supply unit/s                 | Connect to an electric outlet, one module is included.                                                                                                                                                                                                                                                                                                                             |
| 3    | Fixed cooling fans                  | Numbered from right to left 1, 2, 3, 4.                                                                                                                                                                                                                                                                                                                                            |
| 4    | Main power switch                   | When the appliance is turned off, turns the appliance on. When the appliance is turned on, pressing and releasing the switch will start an orderly shutdown process. Alternatively, holding the switch for 4 seconds will force a machine shut down.                                                                                                                               |
| 5    | Location LED                        | <ul style="list-style-type: none"> <li>■ Off - Location beacon is turned off</li> <li>■ Solid blue - Location beacon is turned on through the <b>Gaia Portal</b> or <b>Gaia Clish</b> or through the <b>Locator</b> button on the front panel</li> </ul> <p>Note - You can turn off the Location beacon LED from the Locator button, <b>Gaia Portal</b>, or <b>Gaia Clish</b>.</p> |
| 6    | ESD grounding plug                  | When servicing the appliance, connect an ESD strap to this plug.                                                                                                                                                                                                                                                                                                                   |
| 7    | Grounding lug                       | When using a DC power supply unit (PSU), use the grounding lug that is located on the DC PSU.                                                                                                                                                                                                                                                                                      |

## Using the Power Cable Restraint Strip


You can use the power cable restraint to prevent accidental removal of the power cable.




| Item | Description         |
|------|---------------------|
| 1    | Restraint anchor    |
| 2    | Cable loop          |
| 3    | Restraint strip tab |
| 4    | Restraint strip     |

### To install the power cable restraint strip:

1. If a power cable is connected to the power supply inlet, disconnect it.
2. Unscrew the screw directly above the power supply inlet.



3. Make sure the cable loop on the restraint strip faces the power supply inlet.
4. Insert the restraint strip anchor into the slot and screw it in until it locks.



5. Connect the power cable to the power supply inlet.
6. Move the cable loop on the restraint strip.
7. Move the cable loop until you can put it around the power cable.
8. Insert the open side of the cable loop into the loop slot until it is tight against the power cable.
9. Make sure the cable loop is secured and the power cable cannot be removed.

## Dual Redundant BIOS

To ensure resilience in the event of a BIOS failure, Smart-1 600-S appliances are equipped with dual redundant BIOS images.

If an appliance encounters a BIOS failure, it will boot up from a recovery, read-only BIOS image that enables full functionality of the appliance.

These notifications are shown in the event of a BIOS failure:

- The appliance's Alert LED on the front panel will blink red.
- The **Gaia WebUI Hardware Health** window shows that the BIOS sensor is Invalid and its status is Off.
- An SNMP trap message (if the biosFailure trap was configured in the WebUI or through clish).

|                    |                                                         |            |            |               |   |
|--------------------|---------------------------------------------------------|------------|------------|---------------|---|
| Source:            | 10.48.0.92                                              | Timestamp: | 20 seconds | SNMP Version: | 2 |
| Trap OID:          | .1.3.6.1.4.1.2620.1.3000.20.1                           |            |            |               |   |
| Variable Bindings: |                                                         |            |            |               |   |
| Name:              | iso.org.dod.internet.mgmt.mib-2.system.sysUpTime.0      |            |            |               |   |
| Value:             | [TimeTicks] 20 seconds (2001)                           |            |            |               |   |
| Name:              | snmpTrapOID                                             |            |            |               |   |
| Value:             | [OID] .1.3.6.1.4.1.2620.1.3000.20.1                     |            |            |               |   |
| Name:              | .1.3.6.1.4.1.2620.1.3000.0.12.0                         |            |            |               |   |
| Value:             | [OctetString] the BIOS has failed, using recovery BIOS. |            |            |               |   |
| Description:       |                                                         |            |            |               |   |

To recover from a BIOS failure, see [sk108517](#) or contact Check Point support. The appliance is fully functional until the BIOS recovery is completed.

Maintenance ▸ **Hardware Health**

Hardware Health

Refresh

| Sensor                                                                                                      | Value         | Status                                                                               |
|-------------------------------------------------------------------------------------------------------------|---------------|--------------------------------------------------------------------------------------|
|  VDIMM Voltage             | 1.50 Volt     |  Ok |
|  VBAT3 Voltage             | 3.02 Volt     |  Ok |
|  System Intake Temperature | 37.00 Celsius |  Ok |
|  System Outlet Temperature | 41.00 Celsius |  Ok |
|  CPU Temperature           | 47.50 Celsius |  Ok |
|  CPU Fan Speed             | 1917.50 RPM   |  Ok |
|  BIOS                      | Valid         |  Ok |

## Replacing and Upgrading Components

The Smart-1 600-S appliances have parts that you can easily replace to minimize downtime. There are also components that you can install to upgrade the appliance. These are the parts and components that can be used with the appliance:

- Telescopic rails (optional)
- System memory

For more information about installing these parts and components, see the [Smart-1 600-S/600-M/6000-L/6000-XL home page](#).

Unless directed to do so by Check Point technical support, you are prohibited by warranty and support agreements from replacing any parts.

# Restoring Factory Defaults

If necessary, restore the appliance to its factory default settings.



**Important** - If you restore factory defaults, note that all information on the appliance is deleted.

## Restoring from the Gaia Portal

Use the **Gaia Portal** to restore the appliance to the factory default settings.

To restore a **Gaia** appliance from the **Gaia Portal**:

1. In your web browser, connect to the management IP address:

```
https://<Appliance_IP_Address>
```

2. Log in to the **Gaia Portal** of the appliance with the administrator username and password.
3. In the left navigation tree, click **Maintenance > Factory Defaults**.

The **Factory Defaults** window opens. The image installed on the appliance is shown.

4. Click **Apply**.

The appliance reboots and installs the selected version from scratch.

## Restoring from the Boot Menu

To restore the appliance from the **Boot Menu**:

1. Connect the supplied serial cable's RJ45 or USB type-C connector to the console port on the front of the appliance.
2. From the computer, open a terminal emulation program such as PuTTY or Microsoft HyperTerminal.
3. Configure the terminal emulation program:
  - In the PuTTY window, select the **Serial** connection type.
  - In the HyperTerminal **Connect To** window, select a port from the **Connect using** list.
4. Define the serial port settings:  
9600 bps, 8 bits, no parity, 1 stop bit
5. From the **Flow control** list, select **None**.
6. Connect to the appliance.
7. Reboot or turn on the appliance.

The appliance initializes and status messages are shown in the terminal emulation program.

8. When the message "**Press any key to see the boot menu**" is shown, you have approximately four seconds to hit any key to activate the **Boot** menu.
9. From the **Boot** menu, select the relevant **Reset to factory defaults** image.
10. Press **Enter**.

The appliance initializes and status messages are shown in the terminal emulation program.

## Restoring from Gaia Clish

To restore the appliance from Gaia Clish:

1. Connect to the command line on the appliance.
2. Log in to **Gaia Clish**.
3. Run:

```
set fcd revert <Image_Name>
```

Example:

```
Gaia> set fcd revert Gaia_R81
Warning! This command will erase all the current configuration on this
appliance and will revert it to the selected image.
Are you sure you want to continue such action? (Yes/No) [No]
yes

Reverting to factory defaults Gaia_R81
Gaia>

INIT: Sending processes the TERM signal
```

# Registration and Support

## Registration

The appliance requires a product-specific Check Point license.

Connect to the **Portal** of the appliance (from **Advanced** mode, select **Maintenance > Licenses**) to find the MAC address that is required to obtain a license.

Alternatively, you can read the MAC address off the service tag on the appliance. Refer to ["Front Panel" on page 27](#).

## Support

For additional technical information about Check Point products, consult the [Check Point Support Center](#).

## Where To From Here?

You have the basics to get started. The next step is to get more advanced knowledge of your Check Point software.